EnerPlex
Always in Charge

Jumpr Max ™ User Manual

Configuration:
Two USB Output Ports/Micro USB Input Port

Contents:
Jumpr Prime
USB/Micro USB Charging Cable

Features:
1. 10,000mAh capacity
2. 2 USB output ports 5VDC, 1A and 5VDC, 2A
3. Input: DC Input1:DC5V/1A(max
4. Output:DC5V/1A ,DC 5V/2A
5. Operation temperature: 0°C~40°C.
6. Weight: 192g
7. Product Size: 123*76*16mm

How to use:
To Charge the Jumpr MAX: Connect the Jumpr MAX to a power source using the included micro USB input to charge it.

Charge your device by the Jumpr Max:

How to charge 5VDC, 1 Amp devices
Connect any of your electronic devices to the 5VDC, 1Amp output jack next to the Right most LED on the front edge of the power bank output with the included EnerPlex MAX's Micro USB Cable. To begin charging, Press the on/off switch on the face of the power bank.

How to charge 5VDC, 2 Amp devices:
Connect any of your electronic devices to the 5VDC, 2 Amp output jack next to the Left most LED on the front edge of the power bank output with the included EnerPlex MAX's Micro USB Cable. To begin charging, Press the on/off switch on the face of the power bank.

Caution: Verify that your device can handle a 2 Amp charging routine. Damage to your device can occur when using a higher rated charging current

Cautions and Warnings:
Please read the following carefully before using the Product. Incorrect usage or incompatibility with your device may result in reduced battery performance or damage to your device. If the EnerPlex Max detects the output exceed its limitation, it will turn off the output automatically. To keep the EnerPlex Max performance, if unused for a long time, charge the battery before use(85% remaining least). Re-charge it every half year(85% remaining least).

1. Check device voltage and current for compatibility with this product.
2. Do not attempt to disassemble the product.
3. Do not submerge this product in liquids. Keep out of rain.
4. Do not place this product near a heat source or open flame since it may explode.
5. Do not shake or throw the power bank.
6. Do not operate the power bank if it has been subjected to shock or damage.
7. Do not crush or puncture the battery.

Battery Status Indication
The Indicator status while being charged
● Indicator is on
○ Indicator is off
※Indicator is blinking

Battery Status Indicator	Battery Level
※○○○	0%~25%
●※○○	25%~50%
●●※○	50%~75%
●●●※	Over 75%
●●●●	100%

Warranty:
1 year limited Warranty
Please refer to goenerplex.com for more information

Other EnerPlex Gear see the latest at www.gonerplex.com

Kickr™ Series
- Kickr™ II- 1 Panel, 3 Watt, 5 Volt Portable Solar Charger
- Kickr™ IV - 4 Panel, 6.5 Watt, 5 Volt Portable Solar Charger

Surfr™ Series
- Solar Integrated Battery Cases for the IPhone 5/5S and
- Samsung Galaxy S4.

Jumpr™ Series
- Jumpr™ Mini- Small, compact 1350 mAh battery.
- Jumpr™ Stack- 3 stackable 1600 mAh batteries that can charge simultaneously through a provided charging base.
- Jumpr™ Prime- Small, compact 4400 mAh battery.
- Jumpr™ Max- Portable 10,000 mAh battery.

FC CE RoHS

Made in USA/China

Rev. 2-10-14